



NOTE:

- ENSURE THAT GALVANIZED LATH AND STAPLES DO NOT COME IN CONTACT WITH COPPER FASCIA METAL.
- ALLOW THE PD RESIN TO DRY BEFORE INSTALLING THE PLI-DEK BASE COAT.
- LATHING TO BE NAILED DOWN OVER COPPER SECTION USING STAINLESS STEEL NAILS

DETAIL-COPPER FLASHING INSTALLATION



41610 Date St., Suite 104 * Murrieta, CA. 92562
 Phone: 800.364.0287 * Fax: 951.834.9555
 WWW.PLIIDEK.COM

These waterproofing procedures are not to be used for permit and should be reviewed by the project architect. The waterproofing procedures are not complete plans or specifications and a professional design professional should be contacted prior to performing major waterproofing and repairs.

System: Pli-Dek System
 ICC-ES ESR-2097
 Detail: Copper Flashing Installation

Job:
 Date: 05-3-2013
 Dwn: H.K

Drawing Number:
PD-C-1