



NOTES:

- ALL VERTICAL FLASHING MUST BE MINIMUM 4" ABOVE SLOPING AND DECK FINISHES
- THE Pli-DEK SYSTEM IS INSTALLED UP TO THE BASE COAT STAGE PRIOR TO INSTALLATION OF SLOPING MATERIAL.
- WHEN USING IN CONJUNCTION WITH Pli-DEK SYSTEM, APPLY SLOPE MATERIAL PRIOR TO INSTALLATION OF FIBERGLASS AND PD RESIN.
- CRICKET LOCATION VARIES ACCORDING TO DRAIN/SCUPPER LOCATIONS.
- REFER TO Pli-DEK APPLICATION INSTRUCTION AND SPECIFICATIONS FOR INSTALLATION GUIDELINES.

DETAIL-ENCLOSED DECK DRAINAGE CRICKET

SCALE: N.T.S.



These waterproofing procedures are not to be used for permit and should be reviewed by the project architect. The waterproofing procedures are not complete plans or specifications and a professional design professional should be contacted prior to performing major waterproofing and repairs.

System: Pli-Dek System
ICC-ES ESR-2097
Detail: ENCLOSED DECK LOW
WALL DRAINAGE CRICKET

Job: _____
Date: 11/01/2020
Dwn: E.L.

Drawing Number:
PD-21