



NOTE:

- ENSURE THAT GALVANIZED LATH AND STAPLES DO NOT COME IN CONTACT WITH COPPER FASCIA METAL.
- ALLOW THE PD RESIN TO DRY BEFORE INSTALLING THE PLI-DEK BASE COAT.

DETAIL-COPPER FLASHING INSTALLATION- INCLEMENT WEATHER

41610 Date St., Suite 104 * Murrieta, CA. 92562
 Phone: 800.364.0287 * Fax: 951.834.9555
 WWW.PLIIDEK.COM

These waterproofing procedures are not to be used for permit and should be reviewed by the project architect. The waterproofing procedures are not complete plans or specifications and a professional design professional should be contacted prior to performing major waterproofing and repairs.

Detail: Pli-Dek System
 ICC-ES ESR-2097
 Copper Flashing Installation- INCLEMENT WEATHER

Job:	
Date:	05-3-2013
Dwn:	H.K

Drawing Number:
PD-C-1-IW