

## RESINYTE “TS” SYSTEM TROWELED SLURRY EPOXY FLOOR COATING

### MATERIALS

1. PD Vapor Prime
2. RS-Membrane
3. Resinyte™ Epoxy 100 (Clear)
4. Resinyte™ Epoxy 150 (Pigmented)
5. Color Vial
6. Blended Aggregate
7. Colored Quartz
8. Urethane 100/150

### TOOLS

1. Electric low speed drill – ½”-3/8” with mixing blade
2. Extension cord – grounded
3. Clean 5-gallon plastic containers
4. Electric blower
5. Electric floor grinder with dust muzzle attachment
6. Industrial vacuum
7. Metal floor scraper
8. Utility knife
9. Scissors
10. Masking tape
11. Small paint brushes
12. Paint rollers – 1/8” short nap & 3/8” medium nap
13. Semi-stiff broom
14. Dust mask
15. Protective eye wear
16. Metal spiked shoes
17. Rubber gloves
18. Floor squeegee – notched & flat
19. Rags and cleaning solvent

### I. Substrate Inspection/ Preparation

#### A. GENERAL

1. The Resinyte “TS” Flooring System may be applied over interior structurally sound, code compliant, cured, and profiled concrete substrates. All spalled, severely cracked and decomposing concrete shall be removed and replaced.
2. All inspections, as required by local building authorities, shall be the responsibility of the contractor, owner, and/or their agent.
3. Curing of concrete shall be 28 days before any Pli-Dek Systems, Inc. coating shall be applied to the surface. If any other product, other than water cure is used, the general contractor, and/or the owner, must notify Pli-Dek Systems, Inc. in writing.
4. All concrete substrates not poured over an effective vapor barrier are subject to possible moisture vapor transmissions and related high levels of alkalinity that may lead to adverse effects of the coating. It is the general contractor/owner’s responsibility to ensure proper vapor barriers are in place. Please refer to Moisture & Vapor Transmission Testing refer

to Concrete Moisture & Vapor Transmission Testing Technical Bulletin (TB-111).

5. Concrete areas that require drainage should be positively sloped towards drains as per the code. A minimum of 1/8” to 1/4” per linear foot is recommended.

#### B. PREPARATION

1. All concrete surfaces must be cleaned to remove all contaminants, grease, oil, dust, paint, sealers, efflorescence, curing compounds, etc. that may impair adhesion. The entire surface must be properly profiled by shot blasting or mechanical scarifying to achieve a minimum CSP-2 Rating, suitable to receive the coating.
2. Ensure preparation procedures comply with local building and environmental regulations.
3. Fill in all minor nicks, ruts, and cracks using Resinyte Repair Compound. All cracks are to be treated after the primer application. Pli-Dek Systems, Inc. is not responsible for the integrity of the substrate, thus Pli-Dek Systems does not warrant the crack/repair treatment process. Imperfections in the existing substrate may affect the finished surface. \*\*Contact Pli-Dek Systems, Inc. for details.
4. Ensure that working conditions are conducive of proper application. The area must provide a stable and dry working environment.

### II. Mixing Instructions

#### A. PD VAPOR PRIME, MEMBRANE, EPOXY 100/150, URETHANE 100/150

1. Pre-mix each component separately. Mix Part A with Part B, into a clean container and mix thoroughly with a low speed (400-600 rpm) drill motor for 3 minutes. Use care not to allow the entrapment of air into the mixture. Make sure to scrape the sides and bottom of the container during mixing. Mix only the amount of material that can be used within the pot life.
2. If a color pack is utilized, ensure to completely empty the contents of component A and the Color Vial into a clean mixing container. Care must be taken to ensure all material is scraped from the sides, bottom, and mix at a low speed for approximately 2 minutes. Then add all contents of component B, scraping the sides, bottom, and mix for an addition minute at a low speed.
3. The “pot life” of the mixed epoxy will vary according to temperatures, mass, and mixing duration. Ensure an adequate work force is present to accommodate each batch mix. For large areas it is recommended to box mix the colored resins to ensure color consistency. Care must be taken as to no entrap air into the

mixture. Care must be taken not to entrap air into the mixture.

### III. Application

#### A. GENERAL APPLICATION

1. If necessary based on job site conditions and/or moisture vapor transmission, prime the surface with PD-Vapor Prime with a 3/32" notched squeegee and back roll with a 3/8" non-shedding nap roller. Application rate is approximately 225 sq. ft. per gallon depending on substrate porosity. Allow to cure to for a minimum of 12 hours prior to application of subsequent applications. Do not exceed 24 hours between coats.
2. If waterproofing is required, apply the RS-Membrane with a squeegee at a rate of approximately 80 sq. ft. per gallon. Consult Pli-Dek Systems, Inc. regarding the use of the optional reinforcement fabric.
3. After mixing the Resinyte™ Epoxy 100 or Resinyte™ Epoxy 150 in accordance with section II, combine approximately 50-70 pounds of RS-Blended Aggregate to one gallon of properly blended epoxy and mix until a uniform consistency is achieved. Apply this mixture by trowel and gauge rake to the desired thickness of 3/16"- 1/4" at a spread rate of 25-28 sq. ft per mixed gallon.

#### B. COLORED QUARTZ FINISH OPTION

1. Prior to cure of the Resinyte™ Epoxy 100 or Resinyte™ Epoxy 150, broadcast the desired Colored Quartz into the wet/uncured epoxy until refusal. During production, leave an approximate 1' perimeter of wet epoxy (without aggregate broadcasted) so that the installer can always ensure a "wet edge". Care must be taken when broadcasting the Colored Quartz as to ensure the quartz drops vertically on the surface and the entire area is completely covered with quartz as to achieve a "dry" look. While walking on the uncured epoxy wear spiked or golf shoes and ensure that the areas that have received the broadcast are not walked on. The net coverage rate of the Colored Quartz is approximately .5 pounds per sq. ft. ALL COLOR QUARTZ SHOULD BE BOX MIXED PRIOR TO APPLICATION.
2. If a single color quartz system is desired proceed to step #7.
3. If a double broadcast is desired, mix the Resinyte™ Epoxy 100 or Resinyte™ Epoxy 150 in accordance with section II and apply over the previous cured quartz coat at a rate of 120 sq. ft. per gallon using a notched squeegee and back rolling with a 3/8" non-shedding nap roller; perimeter to be cut in prior with a paintbrush. Proceed with the Colored Quartz broadcast as described in step #1.
4. After at least twelve hours of dry time, remove the excess quartz and lightly scrap the surface as to ensure a uniform surface. Vacuum the entire surface thoroughly. After mixing the

Resinyte™ Epoxy 100 or Resinyte™ Epoxy 150 in accordance with section II, immediately apply the Epoxy 100 or Resinyte™ Epoxy 150 at an approximate rate of 120 sq. ft. per gallon using a notched squeegee and back rolling with a 3/8" non-shedding nap roller; perimeter to be cut in prior with a paintbrush. Additional coats may be applied if a smoother finish is desired.

5. If it is desired to limit yellowing, lightly abrade the surface with a sanding screen and apply the Urethane 100/150 over cured Resinyte™ Epoxy 100 at a rate of approximately 225-275 sq. ft. per gallon with squeegee and back rolled with a 1/4" non-shedding nap roller.
6. Proceed with a second coat of Resinyte™ Epoxy 100 or Resinyte™ Epoxy 150 as described above.
7. If it is desired to limit yellowing, lightly abrade the surface with a sanding screen and apply the Urethane 100 over cured Resinyte™ Epoxy 100/150 at a rate of approximately 200-250 sq. ft. per gallon with squeegee and back rolled with a 1/4" non-shedding nap roller.

#### C. CLEAN UP

1. Uncured material can be removed with a solvent. Cured material can only be removed mechanically; care must be taken.

#### D. LIMITATIONS

1. Care must be taken during application; proper protective clothing, eyewear, and respirators should be used at all times.
2. Please note that the Resinyte "TS" Epoxy System is designed for interior concrete use only and the product is not UV stable and will cause yellowing/ adverse effects. Consult Pli-Dek Systems, Inc. for specific recommendations. Ensure that all control/expansion joints are honored in the application process.
3. The ambient air temperature should be no less than 45°F and not exceed 100°F. The substrate temperature should not be below 55°F and should not exceed 90°F. These conditions should remain so for at least 24 hours.
4. Care must be taken to ensure that the product is applied in a uniform fashion; the products should not be allowed to puddle.
5. Minimum re-coat time between coats is 12 - 24 hours.
6. The referenced coverage rates on the products are estimated, actual coverage rates will vary due to preferred application method, substrate porosity, job conditions, etc.
7. This document works in conjunction with the Resinyte "TS" Specification, TS-110.

### IV. Slip and Fall Precautions

OSHA, American Disabilities Act (ADA), and The Federal Housing Act (FHA) have now set enforceable standards for slip-resistance on

pedestrian surfaces. Pli-Dek Systems, Inc. recommends the use of angular slip-resistant aggregate in all coatings or flooring systems that may be exposed to wet, oily/greasy, or otherwise potentially slippery conditions. It is the end user's responsibility to provide a flooring system that meets current safety standards. Pli-Dek Systems, Inc or its sales agents will not be responsible for injury incurred in a slip and fall accident. Please consult local building codes for the current coefficient of friction requirement.

#### **Disclaimer**

Information contained in this specification conforms to standard detail and product recommendations for the installation of the Pli-Dek products as of the date of publication of this document and is presented in good faith. Pli-Dek Systems, Inc. assumes no liability, expressed or implied, as to the architecture, engineering or workmanship of any project. To ensure that you are using the latest, most complete information, contact Pli-Dek Systems, Inc., at:

**41610 Date St, Suite 104  
Murrieta, CA 92562  
Tel.: (800) 364-0287  
Website: [www.plidek.com](http://www.plidek.com)**